

# Why are the Export Video and PTZ controls disabled in Video Viewer/Alarm Monitoring?

Last Modified on 10/06/2022 4:14 am EDT

## Question

Why are the Export Video and PTZ options disabled in Video Viewer/Alarm Monitoring?

## Answer

The export video and PTZ options are disabled whenever the camera view is in matrix mode, or when a static template is selected.

To use these features, select the single camera view from the **Template Mode** drop-down.

## Applies To

OnGuard (All Versions)

## Additional Information

---