

How can I see occupancy or badge reports in an area using anti-passback?

Last Modified on 10/06/2022 4:15 am EDT

How can I see occupancy or badge reports in an area using anti-passback?

Procedure Steps

To view the report in Alarm Monitoring, right-click on the area and select **Occupancy Report**.

This will display all of the cardholders that are in this specific area. You can select a specific cardholder and move this cardholder to a different area.

Note: This report is only available when using global anti-passback.

Note: The Occupancy Report does not update in real-time, it has a refresh interval.

Applies To

OnGuard (All versions)

Additional Information

None
