

How to upgrade firmware on a Lantronix CoBox Micro

Last Modified on 10/06/2022 4:15 am EDT

How to upgrade firmware on a Lantronix CoBox Micro

Procedure Steps

To upgrade firmware on a Lantronix CoBox Micro loaded with firmware version 5.5 or older, do the following:

1) Download the new firmware file from Lantronix website (<http://www.lantronix.com/>). Save the .rom file in a location that is easy to access (such as **C:** or **C:\Cobox**).

2) Click the Start button, then select **Run**.

3) Type cmd and then click [OK].

4) Navigate to the directory that contains the new firmware.

5) Type the following and then press <Enter>:

```
tftp -i <cobox micro's IP> put <flash filename>.rom 3M
```

6) Type the following and then press <Enter>:

```
tftp -i <cobox micro's IP> put <firmware filename>.rom 4M
```

Applies To

Lantronix CoBox Micro

Additional Information

Lantronix offers several helpful utilities for configuring their products. Please visit their website for additional information: <http://www.lantronix.com/>
