

# Which TCP ports are used by the LNL-3300, X-3300 or LNL-2220, X-2220

Last Modified on 10/06/2022 4:15 am EDT

## Question

Which TCP ports are used by the LNL-3300, X-3300 or LNL-2220, X-2220?

## Answer

The LNL-2220 and LNL-3300 access panels use TCP ports as follows, when connected via Ethernet port.

The LNL-3300, X-3300 or LNL-2220, X-2220 have an internal Web server that listens on port 80 for HTTP traffic, and port 443 for HTTPS traffic (HTTP over SSL). The configuration Web page for the LNL-3300, X-3300 or LNL-2220, X-2220 can be reached via these ports.

The LNL-3300, X-3300 or LNL-2220, X-2220 listen on port 3001 for Communication Server traffic. Port 3001 is the default value, but it can be changed if desired.

## Applies To

OnGuard (All versions)

## Additional Information

None

---