

# How to reset a Cobox Micro

Last Modified on 10/06/2022 4:15 am EDT

How to reset a Cobox Micro

## Procedure Steps

- 1) Press and hold the reset button.
- 2) Continue to hold the button down while powering off the board.
- 3) Continue to hold the button down while powering on the board.
- 4) Continue to hold down the button until the board LEDs light up.
- 5) Release the reset button.

## Applies To

OnGuard (All versions)

## Additional Information

---