

NGP PANELS KEEP GOING OFFLINE AND ONLINE

Last Modified on 10/06/2022 4:15 am EDT

Symptom

NGP PANELS KEEP FLUCTUATING ON AND OFFLINE

Resolution

GO INTO THE ACS.INI FILE ON THE MACHINE RUNNING THE LS COMMUNICATION SERVER AND CHANGE THESE SETTINGS

IN THE SERVICE SECTION CHANGE MAXPANELSPERTHREAD FROM 8 TO 1

```
[Service]
```

```
MaxPanelsPerThread=1
```

ADD AN NGP SECTION WITH THE FOLLOWING LINES

```
[NGP] DefaultReadTimeout=120
```

```
ForceFirmwareDownload=1
```

```
FWDDownloadReadTimeout=90 PollPanelDelay=100
```

```
DefaultReadTimeout=90
```

SAVE YOUR ACS.INI FILE IN DIRECTORY C:\WINDOWS

RESTART THE COMMUNICATION SERVER AND REBOOT THE PANEL

Applies To

OnGuard (All versions)

Additional Information
