

How to enter a new PIN code on an active Schlage SERIII-W Scramble Keypad

Last Modified on 10/06/2022 4:16 am EDT

How to enter a new PIN code on a Schlage SERIII-W Scramble Keypad when the keypad is still active

Procedure Steps

If a cardholder approaches a Schlage SERIII-W Scramble Keypad, and all keys on the reader are illuminated, the cardholder can perform the following steps to enter the PIN and gain access.

- 1) Press the star [*] key.
- 2) Press the pound [#] key.
- 3) Enter the correct PIN code.

If a cardholder approaches a Schlage SERIII-W Scramble Keypad, and only the star [*] key is illuminated, the cardholder can perform the following steps to enter the PIN and gain access.

- 1) Press the * (star) key.
- 2) Enter the correct PIN code.

Applies To

OnGuard (All versions)

Additional Information

None
