Schlage locks and double card unlock/toggle

Procedure Name

Schlage locks and double card unlock/toggle

Procedure Steps

When swiping double card badge on Schlage Locks, the lock state is toggling between the Unlocked and Secure state, even without selecting Double Card unlock/toggle setting.

When the lock is in Classroom/Office mode, Double card unlock/toggle is configured by default. Valid toggle Credentials on the exterior may be used to change to a passage (unlocked) or secured status.

Applies to

Schlage Locks/AD400

Additional Information