

# Using a Keypad for Card and PIN verification with iCam 4000v

Last Modified on 10/06/2022 4:16 am EDT

Using a Keypad for Card and PIN verification with iCam 4000v

## Procedure Steps

1. Wire the iCam 4010v to a LNL-1320 reader port as described in the documentation.
2. Wire a compatible keypad to the other LNL-1320 reader port as described in the documentation.
3. Configure the iCam 4010V reader in System Administration.
4. Set the reader mode to Card and PIN.
5. Configure the keypad in System Administration as an Alternate Reader to the iCam reader.

At the iCam, the cardholder performs the following steps to obtain an Access Granted:

1. Present the badge to the integrated reader.
2. Present eyes for identity verification.
3. Enter PIN on keypad. The iCam unit is seen as a Wiegand reader by OnGuard, so this is no different than setting up any standard reader with a keypad as alternate.

## Applies To

OnGuard (All versions)

## Additional Information

---