

# Controller Encryption is not displayed as an option

Last Modified on 10/06/2022 4:16 am EDT

## Symptom

The Controller Encryption Tab is not displayed in **System Administration > Administration Menu > System Options** (non-segmented system) or **System Administration > Segments** (segmented systems).

## Resolution

There are two reasons why the Controller Encryption Tab does not display:

- **Permissions:** The OnGuard User must have the Access Control, Controller Encryption permission in the assigned System Permission Group.
- **FIPS mode is enabled:** In **System Administration > Administration Menu > General System Options Tab**, there is a check box to enable FIPS mode Controller encryption. If this box is checked, the Controller Encryption Tab will not display.

## Applies To

OnGuard (All versions)

## Additional Information

Be sure that the system is NOT using FIPS mode encryption before deselecting the option. For more information, refer to the FIPS Mode for ISC Communication User Guide.

---