

How do I correctly setup SIA/CID communications on my NGP panel?

Last Modified on 10/06/2022 4:16 am EDT

Question

How do I correctly setup SIA/CID communications on my NGP panel?

Answer

When you enable SIA/CID for an NGP panel, you must also enable the STU communications tab, but leave Line Fail Detection configured as **Not Supported**.

Applies To

OnGuard (All versions)

Additional Information
