

Configuring Custom IP for Elevator Dispatch

Last Modified on 10/06/2022 4:16 am EDT

Otis Compass V3

Procedure Steps

OnGuard 7.3.345 is the first version of OnGuard to allow a custom IP address to be configured for the Elevator Dispatch with Otis Compass V3.

1. Backup the ACS.ini file.
2. Open Notepad as Administration.
3. Click File > Open and browse to the live copy of the Acs.ini file.
4. On a blank line, add in an [Otis] section (including the brackets).
5. Add the following settings under [Otis]:

```
DESHeartbeatAddress= 234.46.30.7
```

```
SecuritySystemIPAddress = IP Address Of Commuication Server
```

```
HeartbeatThreadTTL= 10
```

Applies To

Otis Compass V3

Additional Information

Be sure to update the terminal addresses as need. The last two octets of the IP address make up the terminal address.
