

# LNL-2210 onboard reader is missing the Aux Output tab in OnGuard 7.2

Last Modified on 10/06/2022 4:16 am EDT

## Symptom

When using OnGuard 7.2.269.0 and viewing the onboard reader that is connected to LNL-2210 under **Readers and Doors**, the **Aux Outputs** tab is missing in OnGuard 7.2.269.0.

## Resolution

This issue was corrected in 7.2.269.67.

## Applies To

OnGuard 7.2.269.0

## Additional Information

---