

Custom Open Line Active on Door Contact & Rex Inputs

Last Modified on 10/06/2022 4:16 am EDT

Symptom

If a custom Open Line Event alarm is required from a door contact or REX input, the default Alarm Definitions device list will not display the individual reader inputs.

Resolution

To enable the reader inputs in the device list:

1. Add the following to the acs.ini file:
 - [SystemAdministration]
 - AlarmDefIncludeDCRex=1
2. Restart Comm Server and Reopen System Admin.
3. In System Administration, go to **Monitoring > Alarms > Alarm Definitions** and do the following:
 - a. Add a new definition.
 - b. Enter a name for the new definition.
 - c. In the Hardware list, you will now see **Door Contacts**. Select the Door Contact for the reader.
 - d. Select **Open Line Alarm Active** for the event.
 - e. Assign it over to the right.
 - f. Click [OK]
4. Refresh your alarm configuration, or restart Alarm Monitoring.
5. You should see the custom alarm for the door contact.

Applies To

OnGuard (All versions)

Additional Information