Enable Opening and Closing reports on NGP panels in OnGuard 6.4.500 TU1

How do I enable Opening and Closing reports on NGP panels in 6.4.500 TU1?

Procedure Steps

Use the following SQL query:

UPDATE AREA_NGP SET REPORT_MODE = 1 where AREA_NGP.AREAAPBID = X

where X is the ID of the area you want to update.

AREAAPBID is listed under dbo.AREA_NGP.

Applies To

OnGuard 2010 Technology Update (6.4.500 TU)

Additional Information